

## **COMMON APPLICATION**







## We generate FREEDOM for LIVING

Diesel and soundproof motorization stand for reliability with low operating cost in the maximum comfort. Handle and wheels allow easy move and transportation. Generous fuel tank capacity allows for long continuous running time. Built-in digital multimeter for scheduled maintenance intervals and ensure optimal operating condition. Automatic Voltage Regulator (AVR) allows for tension stability. Connector for Pramac Automatic Transfer Switch (ATS) to electrical grid - optional. Power coated finish helps to prevent corrosion in all weather conditions.

	FREQUENCY 50 Hz	
	PMD 5000s	PMD 5050s
Three Phase Max Power		5000 Watts
Three Phase Rated Power		4500 Watts
Single Phase Max Power	5000 Watts	1660 Watts
Single Phase Rated Power	4500 Watts	1500 Watts
Voltage	230 V	230 / 400 V
Running time at 50% of load	11.3 Hours	11.3 Hours
Tank Capacity	14.5 Litres	14.5 Litres
Fuel	Diesel	Diesel
Displacement	418 cc	418 cc
Speed	3000 rpm	3000 rpm
Starting System	Electric	Electric
Guaranteed sound level (LWA)	97	97
Noise emission at 7 m	69	69
Dimensions LxWxH (mm)	910x518x682 mm	910x518x682 mm
Dry Weight	150 Kg	161 Kg
Socket type	1 x Schuko 230V 16A - 1 x CEE 230V 32A	1 x Schuko 230V 16A - 1 x CEE 400V 16A
Battery charger	12V DC	12V DC
Oil guard	$\sqrt{}$	$\checkmark$
Fuel level gauge	$\sqrt{}$	$\sqrt{}$
Thermal Magnetic breaker	$\sqrt{}$	$\checkmark$
Hour meter	$\sqrt{}$	$\sqrt{}$
Volt meter	V	$\checkmark$
Frequency meter	$\sqrt{}$	$\checkmark$
Wheel kit	$\sqrt{}$	$\checkmark$
Connector ATS	$\checkmark$	$\checkmark$







Robust components combined with generous fuel tank capacity stands for reliability with low operating cost. The Automatic Transfer Switch (ATS) - optional - offers the comfort of prompt start up in case of outage. The reliable choice of conscious homeowners.



- A) Central lifting point
- B) Control panel with digital display (Hourmeter / Voltmeter / Frequencymeter)
- C) 4" wheels for easy transport

- **D)** Low oil shutdown protects engine
- E) Fuel tank with fuel filter and fuel gauge
- F) AVR Automatic Voltage Regulator
- **G)** Connector to Automatic Transfer Switch for an optimal home safety









Distributed by

For more information visit us online at **www.pramac.com** 

## PR INDUSTRIAL S.R.L.

Località II Piano, 53031 Casole d'Elsa (SI) Italy Tel. +39 0577 9651, Fax: +39 0577 949076 info@pramac.com / www.pramac.com

Worldwide Service & Parts
Online Center: www.pramacparts.com

© 2018 | **PR INDUSTRIAL S.R.L.** | All rights reserved Image shown may not reflect actual package. Specifications subject to change without notice.



